



How to Add a Password to a User Profile on Your ActivPanel Nickel


Your ActivPanel Nickel has User Profiles that enable multiple educators to make the most of a single ActivPanel. To create a PIN for your new user profile, select the **Unified Menu**, then tap **User**, which in this case reads **Owner**. Next, select the **lock** icon.



To lock your user profile, select **Screen lock**, then tap **PIN**.



Enter a PIN between 4 and 17 digits. Select **Continue**. You will be prompted to confirm your PIN. Tap **OK**. Next, determine your preference for Notifications and tap **Done**.



To sign out, select the **Unified Menu**, then **User**, and sign out. You will be returned to the Sign-in screen. When you select your profile again to sign back in, you will be prompted to enter your PIN. Owners may also add a PIN for security using the same process as previously shown.

To change or remove your PIN, sign in to your user profile. From the **Unified Menu**, tap **Locker**. Select the **Settings** tab, then **More Settings**. Tap **Security & Location**. Select **Screen Lock**. You will be prompted to enter your existing PIN once more. From here, select **None** to remove the PIN altogether, or tap **PIN** to change your password.

Follow us on Twitter [@LearnPromethean](#), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

