

CONNECTING YOUR OWN DEVICE

Learn how to connect an external PC, Macbook or Chromebook to your ActivPanel.

You will find plenty of connectivity options on the ActivPanel directly to the left of the center console, as well as on the left side of the ActivPanel bezel. Depending on your device's connectivity options, you'll need a USB- and HDMI cable, or a USB-C cable.

Connect with HDMI+USB

Use the included USB and HDMI cables, to connect your device. The HDMI cable provides picture and sound, while the USB cable provides touch connection.

It's important to connect **both** cables, if you want to be able to operate your laptop from the ActivPanel.




Make sure to connect the cables in pairs. If, for example, using the **HDMI 2** input on the side of the screen, the USB cable must be connected to the **TOUCH 2** input and so forth.

Connect with USB-C

If your device has a USB-C port, you can use the included USB-C cable instead..

The ActivPanel's USB-C port is located on the left side of the screen, just above the HDMI 2 input.



 Always use the cables included with your ActivPanel. There are differences with HDMI and USB cables and full functionality for third-party cables cannot be guaranteed.



Switch source

Once your device is powered on and connected properly, switch source either from the center console, or the remote.

