PRM EMEA NE/EE ActivPanel 9





SIGN IN WITH NFC OR ACTIVSYNC

Learn how to sign in to ActivPanel 9 Premium, using NFC or ActivSync.

ActivPanel 9 Premium offers two additional sign in methods: NFC and ActivSync.

Sign in with NFC

Locate the NFC reader, on the left side of ActivPanel 9 Premium's pen tray.

Tap your NFC Card on the reader and wait a moment for the sign in message.

You can sign out by tapping the NFC card on the NFC reader again.

Sign in with ActivSync

If you have installed the Promethean desktop app to your device and signed in to your Promethean account, you can sign in automatically.

Connect your device with USB+HDMI or USB-C to the ActivPanel and wait for the sign in message.

Disconnecting the cables signs you back out.



