



System Pin Lock


Learn how to set, clear and disable a System Pin Lock on your ActivPanel 9.



System PIN Lock



When first setting up your ActivPanel 9, the very last step allows you to set a System Pin Lock. This pin code will prevent unauthorised use of you ActivPanel, as users will be prompted to enter it, whenever the panel is powered on or wakes up from standby or sleep mode. You can also set this at a later point, by selecting:

Apps → Settings → System → Advanced → System Lock → Modify ActivPanel PIN



Setting, clearing or hiding System PIN Lock Remotely

If your ActivPanel is enrolled in the **Promethean Panel Management** Portal, your IT-Admin can set or remove the System Pin Lock remotely, or even hide the option on the panel, preventing users from unintendedly locking it.



To set the System Pin Lock, go **Device Settings**, locate the device in question and under **Device Details** select **Set Pin**.

Type in and confirm your pin lock code and confirm.

If the PIN already has a PIN set, you can clear it by selecting **Clear PIN**.

To hide the System PIN lock option on your ActivPanel entirely, scroll down to **Device Settings** and ensure you have **Show AP9 System Lock Setting** set to **Off**.

The System PIN Lock will not affect any PIN lock set by individual Promethean Account Users, when signed in.