



ActivPanel LE quick start guide


Caring for your ActivPanel LE

1. Use a 100% cotton or micro-fiber cloth
 
2. Use 70-90% Isopropyl or Ethanol Alcohol/no other cleaners or solvents
 
3. Spritz liquid on to the cloth, never directly to the ActivPanel
 
4. Wipe in single direction
 
5. Ensure all moisture is removed from the ActivPanel after cleaning
6. Check with your district or school for specific ActivPanel cleaning instructions

Interacting with your ActivPanel LE




ActivPanel LE Remote



1. Power
2. Mute
3. Decrease brightness
4. Switch sources
5. Increase brightness
6. Freeze
7. Multi-directional touchpad
8. Volume
9. Back
10. Whiteboard
11. Home
12. Android Settings
13. OPS Source
14. Annotate
15. Other settings

ActivPanel LE Pen




Connecting an external device

Back ports



Front ports



Activating touch features

USB-C

Using a USB-C cord allows for a single cord connection and charges the connected device. Through a USB-C connection, you receive visual and audio connections as well as the touch capabilities of the ActivPanel LE.



The USB-C cord enables the ActivPanel to display visual and audio from the connected device and allows for touch capabilities by only using one cord. Connecting with a USB-C cord also charges the battery of the connected device.

HDMI or DisplayPort paired with Touch display

Using an HDMI cord or a DisplayPort along with a USB touch cord will also connect your laptop or another computer to the ActivPanel LE.



The ActivPanel can be connected using an HDMI and USB touch cord. This type of connection enables audio and visual from the connected device as well as touch capability. Please note: the cords must be plugged into the corresponding ports.

Ex: HDMI 2 and Touch 2 must be used in tandem to enable touch functionality.

Overview of Promethean Classroom Essential apps



Explain Everything Whiteboard

Create dynamic and interactive digital whiteboard lessons to keep your students immersed in the subject. You can start with a blank canvas, import an existing file, or create a project using one of our ready-to-use templates.



Annotate


Write and highlight on top of anything projected on your screen and save those notations directly to your device.

Want to save your annotation to reference later? Take a screenshot directly from your Annotate control bar using the integrated Screen Capture tool.



Timer

Motivate and keep your students on track during your lesson. You can even open multiple timers at a time and save them as templates in your Promethean account.



Spinner

This floating tool adds randomized excitement to your lessons. Launch multiple spinners at a time and save spinner preferences to your Promethean account.



Screen Share

Share and control content from multiple devices, including laptops, desktops, tablets, and mobile devices.