






ActivPanel D-Series quick start guide

Caring for your ActivPanel D-Series


1. Use a 100% cotton or micro-fiber cloth

2. Use 70-90% Isopropyl or Ethanol Alcohol/no other cleaners or solvents

3. Spritz liquid on to the cloth, never directly to the ActivPanel

4. Wipe in single direction

5. Ensure all moisture is removed from the ActivPanel after cleaning
6. Check with your district or school for specific ActivPanel cleaning instructions

ActivPanel D-Series ports



1. USB 2.0 in
2. USB 3.0 in
3. USB-C in
4. DisplayPort in
5. HDMI / HDMI Arc in
6. RS232 In/Out
7. LAN port
8. SPDIF port
9. Audio-out

ActivPanel D-Series navigation buttons



1. Source
2. Left/right navigation buttons
3. Up/down navigation buttons
4. Settings
5. Power

ActivPanel D-Series OPS slot

