

Guided Practice on Your ActivPanel 10 and OPS-A

Power on your ActivPanel 10

- Locate and press the Power button on the console.
- If you have multiple sources connected, use the Source button to switch to the OPS source.
- If the OPS is pin protected, you will need to swipe up and enter the pin/password.





Mome Screen


Below is an overview of the home screen of the OPS-A device.



Applications

- Tap on Applications to access the App Drawer.
- Press and hold on the **Chrome** app. Drag it to a spot on the home screen or in an available spot on the menu along the bottom.
- Repeat the process for the Timer and Spinner apps.








Professional Development

S Explain Everything Whiteboard App

- The Explain Everything Whiteboard will be located in the menu at the bottom of the home screen or in the App Drawer.
- Tap on Explain Everything.
- Press the **Home** icon. Notice you can start with a blank canvas, template, or file. Select **Blank Canvas**.
- Begin writing with multiple points of touch.
- Switch to the Hand Tool to move or resize (pinch) your annotations.
- Change the **background** (color and/or built-in backgrounds) by *long pressing on the canvas* and selecting **Edit Background**. □
- Select the Add Media tool. (+) Notice all the media you can add!
- Select Clipart and add an emoji to the canvas.
- Tap on your emoji to open the object menu. Select the three dots and duplicate your image.
- Select the **Layouts** button and then choose **Split**. Now you have two whiteboards for ultimate student interaction!
- Open another Blank Canvas by tapping on the House in the upper left corner, select Discard, then Blank Canvas.

Create Custom Spinners

- Swipe up from the bottom of the screen to access the menu.
- Tap on Applications to access the App Drawer.
- Locate and tap on the Spinner app.
- Tap the current spinner title and select Create list + from the drop-down menu.
- Title spinner Seasons.
- Enter the 4 seasons: Fall, Winter, Spring, and Summer.
- Tap Done.
- Optional: Tap on settings gear and customize your spinner.
- Move the spinner to the center of the screen.
- Spin your custom spinner by tapping the blue center.
- Create another custom spinner of your choice.
- Tap on the X to close the Spinner when you are done.







Professional Development

Timer

- Tap on Applications to access the App Drawer.
- Locate and tap on the **Timer** app. 🤇
- Tap on the Gear icon to customize Settings and Style.
- Set a 1-minute timer using the up and down arrows above and below the numbers.
- Press play to view your customizations.
- Tap on the X to close the Timer when you are done.

Spinners and timers are a great way to bring friendly competition into the classroom.

Annotate and Capture

- Tap on **Applications** to access the **App Drawer**.
- Locate and tap on the Chrome app.
- Search for a beach image. Go to the Images tab in Chrome. Tap on the picture of your choice.
- Open the Annotate app (located either in the menu at the bottom of the home screen or in the App Drawer).
- Change the pen color and draw yourself on the beach.
- Capture your artwork by tapping on Capture in the Annotate app.



Resize (pinch and zoom using two fingers) the image to make it smaller or bigger.

Screen Share a Device

iPhone, iPad, Android Phone or Tablet

- Swipe up from the bottom of the screen to access the menu.
- Tap on Applications to access the App Drawer.
- Locate and tap on the Screen Share app.
- On your mobile device, download Promethean App from your app store.
- In mobile app, open the app and tap the white Screen Share button.
- Still in mobile app, enter the panel ID shown on the Screen Share app (on the ActivPanel screen) and your name.
- Tap Continue then Start Broadcast.
- On the ActivPanel screen, tap on the people icon that shows the number of people in the waiting room.
- Select the devices you want to share and tap the purple Share button at the bottom of the screen.



Professional Development

Screen Share a Device (continued)

Windows/Mac/Chrome Extension

- Download the Screen Share app for Windows or Mac by going to <u>share.one.prometheanworld.com</u> or add the Screen Share chrome extension.
- Open the Screen Share app on your ActivPanel.
- On the Screen Share app on your device, enter the panel ID and your name and select ENTER WAITING ROOM.
- On the ActivPanel screen, tap on the people icon that shows the number of people in the waiting room.
- Select the devices you want to share and tap the purple Share button at the bottom of the screen.
- When you are finished, tap on the X in the black bar along the bottom of the screen and select Close.

Connect another device to your ActivPanel

- Plug the USB-C cable into the side or front port on the panel.
 If you do not have a USB-C cable, use HDMI and USB Touch cables.
- Plug the cable(s) into your computer.
 You may need an adapter if you do not have an HDMI or USB port on your computer.
- Tap the Source button on the console.
- Tap on the source you've connected to under Main display to change the source.
- Picture in picture:
 - Or you can also tap on the source you just connected to under Picture in picture to utilize 2 touch enabled sources.
 - o To get out of Picture in picture, go back to **Source**, and tap the Picture in picture source again to unselect it.

Resources

- Open the Chrome app.
- Navigate to https://learn.prometheanworld.com/
- Explore Online courses, Video tutorials, Resources, and Learning packs related to the ActivPanel 10 and OPS-A.

