

How to Use the Timer App for ActivConnect OPS-G and ActivConnect G

The Timer app is perfect for managing activities, assessments, and more within your classroom. To access it, tap the **Pink Menu Button**, then the **Timer** app. It resembles a timer and is the second option from the right.



The Timer app opens. There are three modes: Clock, Timer, and Stopwatch. Tap whichever title is currently displaying to toggle between the three modes. Tap the **gear** to access more options in any mode.

Each mode has two viewing options: full screen and floating. Tap the **Expand/Collapse** arrows to toggle between full screen and floating.

Within the Timer mode, choose between presets or use the up and down **arrows** to customize your own Timer. Press the **Start** button to initiate. Use the **Pause** and **Reset** buttons as needed.



Tap the **plus sign** to create a new Clock, Timer, or Stopwatch. You can create and use any combination of up to four at the same time. This applies to both full screen and floating modes.

Tap the **X** to close each Clock, Timer, or Stopwatch.

Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [PrometheanVideo](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

