




How to Use the Spinner App for ActivConnect OPS-G and ActivConnect G

The Promethean Spinner app is perfect for quickly and easily randomizing elements for your class all in one place. To access, tap the **Pink Menu Button**, then the **Spinner** app. It resembles a wheel and is the furthest to the right.



The Spinner app opens. There are three modes – full screen, floating, and condensed. Tap the **Expand/Collapse** arrows to toggle between full screen and floating. To toggle between floating and condensed, tap any segment of the Spinner.

Tap and hold the outer edge to move the floating or condensed spinner anywhere on your screen.



To access six default lists, or to create new lists, select the **list title** directly below the Spinner in either full screen or floating mode.

Tap **Create New** at the top to generate a new list. Give your list a title and input items. Tap **+ Add Item** to input additional items. A list can contain up to 44 items. Be sure to **Save** your list. There is no limit to the number of lists that can exist in the Spinner app.

Within the library of lists, tap the **pencil icon** to the right of a list title to edit an existing list. Select an **item** to make changes. Delete items by tapping the **trash can**. Drag the **equal sign** up or down to rearrange items within the list. Tap the **trash can** at the top of the window to delete a list entirely.

Tap the **gear** icon to access options, including **Select item once** and **Sound**.

To use the Spinner, just drag any segment of the Spinner in a clockwise direction.

Tap the **X** to exit the Spinner app.

Follow us on Twitter [@LearnPromethean](#), subscribe to our [PrometheanVideo](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

