

How to Use the Pink Menu Button for ActivConnect OPS-G and ActivConnect G



1. **BACK BUTTON:** The Back button allows you to navigate back to the previous screen.
2. **HOME:** The Home button allows you to quickly return to the home screen.
3. **PROMETHEAN WHITEBOARD APP:** Turn your classroom display into a blank interactive canvas. Use the annotation tools to write or draw, insert images, and more.
4. **SCREEN CAPTURE:** Instantly capture screenshots of anything displayed on your screen. Annotate directly onto the screenshot using the Promethean Whiteboard App and save if you wish.
5. **PROMETHEAN ANNOTATE APP:** Annotate over anything displayed on your screen quickly and easily.
6. **PROMETHEAN TIMER APP:** Launch up to four clocks, timers, or stopwatches simultaneously for classroom management.
7. **PROMETHEAN SPINNER APP:** Randomize elements of your classroom with ease. Choose from six default lists or create your own.

Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [PrometheanVideo](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

