



How to Close Apps on Your ActivPanel Nickel

To close apps on your Elements Series ActivPanel, select the **Unified Menu**, then tap **Recent Apps**.



Depending on how many apps you currently have open, there may be multiple pages, denoted by small white dots at the bottom of the Recent Apps window. Swipe to the **right** or **left** to navigate between pages.



To close apps, much like you do on your smart phone, simply tap the little **x** to the bottom right of an app.



Follow us on Twitter [@LearnPromethean](#), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

