




## How to Disable the Unified Menu on Your ActivPanel Nickel


In some instances, you may wish to remove the three Unified Menus from your ActivPanel's screen. To do this, access the **Unified Menu**, then tap **Locker**.



Choose the **gear** icon to access **Settings**. Tap **More Settings**.



Tap **Display**.



Toggle the Unified Menu **off**. Use the back arrow to return to your Home screen.

To reinstate the Unified Menu, select the **Unified Menu** button from your ActivPanel remote or tap either of the **volume buttons** on the front of your ActivPanel. This causes the Locker to reappear. From here, you can return to More Settings and toggle the Unified Menu back on.

Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [Promethean Video](https://www.youtube.com/channel/UCqWw0kz0p0p0p0p0p0p0p0p0) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

