



How to Turn Your Speakers On and Off on the ActivPanel Nickel


There may be instances in which you wish to disable your ActivPanel's speakers. To change this setting, begin by accessing your **Unified Menu**, then tap **Locker**.




Next, select the **gear** icon on the left to go to the **Settings** tab within your Locker. Choose **More Settings**.



Within More Settings, select **Audio**.



Toggle the panel speakers off or on to best meet your instructional needs. You may return to this setting at any time.



Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

