



How to Adjust the Volume on Your ActivPanel Titanium

To adjust the volume on your ActivPanel, select the **Unified Menu**, then tap **Locker**.



Choose the **gear icon** to access Settings. **Press and slide** the volume bar forward or backwards until you achieve the desired level.



Follow us on Twitter [@LearnPromethean](#), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

