

## How to Use the Remote on Your ActivPanel Nickel

The Promethean remote allows you to navigate your ActivPanel from anywhere in the classroom.



1. **INSTANT POWER ON:** Turn your ActivPanel on.
2. **NAVIGATE AND SELECT:** Use the arrows to navigate to the option of your choice. Press the checkmark to select your option.
3. **VOLUME:** Use + to increase and – to decrease your ActivPanel's volume.
4. **UNIFIED MENU:** Use to access your Locker and Classroom Essential apps.
5. **SOURCE:** Use to switch to any device connected to your ActivPanel.
6. **BLANK SCREEN:** Use to instantly have nothing visible on the ActivPanel.
7. **FREEZE:** Use to freeze the current image on the screen.

Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

