




How to Uninstall Apps on Your ActivPanel Nickel



To uninstall apps from your Elements Series ActivPanel, select the **Unified Menu**, then tap **Locker**.




Select the **gear** icon to access Settings. Tap **More Settings**.



Select **Apps** from the Settings menu.

Your apps are listed alphabetically. Scroll to the desired app you wish to uninstall and tap its **title**.



Tap the **Uninstall** button to begin the uninstallation process.

You may be prompted once more to confirm your choice to uninstall.

Once uninstallation is complete, you will briefly receive a small confirmation at the bottom of your screen and will be returned to the app list.

Follow us on Twitter [@LearnPromethean](https://twitter.com/LearnPromethean), subscribe to our [Promethean Video](#) YouTube channel, [sign up](#) to hear from us, and [visit our website](#) to learn more.

