Getting Started Playlist

Promethean Help App

Promethean Support

Connections

See
Ensure cables are connected to correct ports and correct Source is selected.

HDMI or **VGA**

Hear
Ensure cables are connected to correct ports and speakers have not been disconnected from Settings.

HDMI or **Audio Jack**

Touch
Ensure cables are connected to correct ports and Touch Off and Freeze buttons have not been selected.

USB