Promethean

How to Use the Promethean Activities Player on Your ActivConnect OPS-G

The Promethean Activities Player provides an easy way to access your pre-created ActivInspire activities and engage your students.

To begin, please be sure your ActivConnect OPS-G is running the most up-to-date software. To update your ActivConnect OPS-G software, please visit support.prometheanworld.com/article/1556.

Next, save one or more ActivInspire activities to a USB, then insert the USB into your ActivPanel. Select the **App Manager**, then the **Communications** tab.

Select **Activities**.

The Activities Player opens. Recently opened activities will display here. Tap the **diagonal arrows** to maximize or minimize the Activity Player.

Tap **Open** to access an activity from your USB. Next, select **Documents**.

Promethean

Within this window, select the **three vertical dots** in the top right corner.

Select **Show SD card**. This allows you to access your ActivPanel's Internal storage and your USB.

Select any of your activities. Again, activities may be played in this window or fullscreen.

Two activities may be open at once for a multi-user experience! Tap the **plus sign** to locate and open a second activity. It could be the same activity, or a different one. Multiple students can practice skills and concepts simultaneously.

Tap the **X** to close an activity. Once you close the final activity, you'll be returned to the main Activities Player window. Tap this **X** to return to the App Manager, or return home by using the pink menu button.

Follow us on Twitter [@LearnPromethean](), subscribe to our [Promethean Video]() YouTube channel, and [visit our website]() to learn more.

Promethean Incorporated | 720 Olive Way, Suite 1500, Seattle, Washington 98101
T: 888.652.2848, select option 2 | PrometheanWorld.com